

17562.0161.0 REV2

Spare parts list M97.23SM Edition 02/2007



Spare parts list

1 REPLACEMENT PARTS CATALOGUE

This catalogue includes all the replacement parts required for the maintenance and service of Biasi boilers. This edition of the catalogue supersedes all previous editions.

2 MODELS AND SPECIFICATIONS

Biasi produces a number of boilers to satisfy a wide range of user needs and installation requirements.

All boilers are wall mounted, with instantaneous operation and modulating heat regulation; that is, the amount of heat from gas combustion is automatically varied according to the heat required by the heating system.

2.1 Maximum useful heating power during operation as a building heat source

The models are available with a maximum useful heating power when used as a building heat source. Each of these models is identified by its own model number:

Model 23

2.2 Fume exhaust method

Forced exhaust from a sealed combustion chamber

These boilers are equipped with a fan which forces the fumes through an adequately—sized exhaust duct system; however, the combustion chamber is enclosed in a sealed chamber and is isolated from the installation area. boilers using this system are identified by the letter "S" in their model number, and do not use air from the installation area for combustion.

2.3 Combi boilers

The combi boilers supply central heating and domestic hot water. Adjustment of the d.h.w temperature is completely separate front that of the c.h. circuit.

3 MODEL IDENTIFICATION CODE/SERIAL NUMBER

Every boiler produced by Biasi carries its own model identification code/serial number.

It is important for the service centre to mention this number when contacting the factory (the number must be listed on guarantee claims and service reports; when making requests for technical information, etc.).

The following is a breakdown of the model identification code/serial number and its meaning (reading from left to right):

- The maximum useful heating power during operation as a building heat source.
- B) The type of boiler according to its functions
- C) The type of gas used by this boiler. The letter "N" is used for Natural gas; the letter "G" is used for liquefied petroleum gas (LPG).
- D) The first five numbers are the actual serial number.
- E) The last four numbers indicate the month (first two numbers) and the year of construction.

These numbers are used in this catalogue to distinguish between versions of the same model with different modifications.

B) Type of boiler

D) Serial number

M97.23SM N210560104

Maximum
 useful heating
 power during
 operation as a
 building heat
 source

C) Type of gas used by this boiler E) Month and year of construction

4 REPLACEMENT PARTS CODE

Each currently available replacement part is uniquely identified by its own replacement parts code. The replacement parts code consists of a table code and a position code.

4.1 Table code

The table code is a sequence of letters and numbers which uniquely and clearly identify each table. The table code can be found on the upper right of each table (see 4.3).

A validity chart for the table is located at the bottom of the table. This chart lists the models covered by the table.

| M97.23SM | |
|----------|--|
| | |
| | |
| | |

4.2 Position Code

The position code is a number which is used to identify a particular object on the table.

To make identification easier, position codes for kits have a different format from position codes for individual parts.

Position code for a kit Position code for an (or assembly) Position code for an individual part 125


A label can be found next to the position code. This label is used to provide additional information on the replacement part and makes identification of the part easier:

A-Type of gas $515_{\rm G20} \qquad 125_{\rm G20} \qquad G20 = {\rm Natural \, gas}$ $515_{\rm G30-G31} \qquad 125_{\rm G30-G31} \qquad G30-G31 = {\rm Butane-Propane \, (LPG)}$ $B-Validity \ restrictions$ $515_{\rm (S)} \qquad 125_{\rm (S)} \qquad {\rm For \, models \, (M97.23SM), \, only}$

4.3 Composition of the replacement part code

Each replacement part code includes a table identification code and a position code. A position code is only listed for replacement parts which are currently available.

The replacement part code consists of the table code (which can be found on the upper right of the table) plus the position code (in two formats: individual part or kit).



The components of a kit are enclosed in a broken line. A kit may contain other complete kits, or portions of other kits.

In some tables, a replacement part may be identified with an arrow and a complete replacement part code (table code + position code). This means that the part is available, but must be ordered with the code listed. Also, any explanatory notes must be read before ordering.

4.4 Using the replacement parts code

The replacement parts code must be included on all documents which are used in service reports, orders for replacement parts, guarantee claims, etc.

Spare parts list


| Table | | Edition | N° of pages |
|---------------|----------------------------------|---------|-------------|
| BI1291 Part 1 | Water group | 0605 | 1 |
| BI1301 Part 1 | Water group | 0605 | 1 |
| BI1352 Part 2 | Water group | 0905 | 1 |
| BI1233 Part 3 | Gas group | 0207 | 1 |
| BI1283 Part 3 | Gas group | 0207 | 1 |
| BI1084 Part 4 | Template and connection group | 0605 | 1 |
| BI1745 Part 5 | Driving panel and electric parts | 0605 | 1 |
| BI1755 Part 5 | Driving panel and electric parts | 0605 | 1 |
| BI1426 Part 6 | External panels, fire chamber | 0905 | 1 |
| BI1911 Part 1 | Spares | 0207 | 1 |

| M97.23SM | | | |
|----------|--|--|--------------|
| | | | ADIACI |
| | | | BIASI |
| | | | |


= BI1181 114

500


0605



| M97.23SM | | | |
|----------|--|--|----------------|
| | | | ADIACI |
| | | | A BIASI |
| | | | |




| M97.23SM | | | |
|----------|--|--|--------------|
| | | | ADIACI |
| | | | BIASI |
| | | | |




Valid from: 07-2006


0207



M97.23SM


ABIASI






| M97.23SM | | | |
|----------|--|--|--------------|
| | | | ADIACI |
| | | | BIASI |
| | | | |

BI1755





| M97.23SM | | | |
|----------|--|--|--------------|
| | | | ADIACI |
| | | | BIASI |
| | | | |



Part 1 - Spares

BI1911





| | 800 | 0-1 | O-ring packing set | | |
|--------|------|-----|--------------------|--|--|
| Part | Pos. | N. | T. Size | | |
| BI1001 | 115 | 10 | 12,42 x 1,78 | | |
| KI1043 | 144 | 10 | 18,64 x 3,53 | | |
| BI1001 | 503 | 10 | | | |
| KI1043 | 114 | 10 | 17,04x3,53 | | |
| KI1001 | 105 | 10 | 17,13x2,62 | | |
| BI1475 | 119 | 10 | 7x2 | | |
| BI1212 | 112 | 10 | 17,04x4,00 | | |

| BI1901 | 802 | Flat packing set | |
|--------|------|------------------|--|
| Part | Pos. | N. T. Size | |
| BI1001 | 107 | 10 P 1/4" | |
| BI1001 | 109 | 10 P 3/8" | |
| BI1202 | 105 | 10 P 3/8" | |
| BI1001 | 106 | 10 P 1/2" | |
| BI1001 | 108 | 10 P 3/4" | |
| BI1001 | 105 | 10 P 1" | |

0207

| M97.23SM | | | |
|----------|--|--|--------------|
| | | | ADIACI |
| | | | BIASI |
| | | | |