

17562.0258.0 REV1

Spare parts list DELTA Edition 11/2009



Spare parts list

1 REPLACEMENT PARTS CATALOGUE

This catalogue includes all the replacement parts required for the maintenance and service of Biasi boilers. This edition of the catalogue supersedes all previous editions.

2 MODELS AND SPECIFICATIONS

Biasi produces a number of boilers to satisfy a wide range of user needs and installation requirements.

All boilers are wall mounted, with instantaneous operation and modulating heat regulation; that is, the amount of heat from gas combustion is automatically varied according to the heat required by the heating system.

2.1 Fume exhaust method

The fumes in the combustion chamber can be exhausted in one of two different ways:

A - Natural drafting (by the atmosphere)

boilers using this system must be connected to an adequately—sized exhaust duct system (chimney), and use air from the installation area for combustion. Boilers using this system are identified by the letter "D" in their model number.

B - Forced exhaust from a sealed combustion chamber

These boilers are equipped with a fan which forces the fumes through an adequately—sized exhaust duct system; however, the combustion chamber is enclosed in a sealed chamber and is isolated from the installation area. boilers using this system are identified by the letter "C" in their model number, and do not use air from the installation area for combustion.

2.2 Combi boilers

The combi boilers supply central heating and domestic hot water. Adjustment of the d.h.w temperature is completely separate front that of the c.h. circuit.

3 MODEL IDENTIFICATION CODE/SERIAL NUMBER

Every boiler produced by Biasi carries its own model identification code/serial number.

It is important for the service centre to mention this number when contacting the factory (the number must be listed on guarantee claims and service reports; when making requests for technical information, etc.).

The following is a breakdown of the model identification code/serial number and its meaning (reading from left to right):

- The maximum useful heating power during operation as a building heat source.
- B) The type of boiler according to its functions

building heat

source

- C) The type of gas used by this boiler. The letter "N" is used for Natural gas; the letter "G" is used for liquefied petroleum gas (LPG).
- D) The first five numbers are the actual serial number.
- E) The last four numbers indicate the month (first two numbers) and the year of construction.

These numbers are used in this catalogue to distinguish between versions of the same model with different modifications.

B) Type of boiler

D) Serial number

M97R.24CM/F N210561109

A) Maximum
useful heating
power during
operation as a

C) Type of gas used
by this boiler

E) Month and
year of construction

4 REPLACEMENT PARTS CODE

Each currently available replacement part is uniquely identified by its own replacement parts code. The replacement parts code consists of a table code and a position code.

4.1 Table code

The table code is a sequence of letters and numbers which uniquely and clearly identify each table. The table code can be found on the upper right of each table (see 4.3).

A validity chart for the table is located at the bottom of the table. This chart lists the models covered by the table.

M97R.24CM/F	
M97.24DM/F	

Some tables bear the leggend "Valid till" and the period (month and year) until those components have been used for production. The following table will bear the legend "Valid from" and the period (month and year) when tose components have first been used for production.

4.2 Position Code

The position code is a number which is used to identify a particular object on the table.

To make identification easier, position codes for kits have a different format from position codes for individual parts.

515 Position code for a kit Position code for an (or assembly) individual part


A label can be found next to the position code. This label is used to provide additional information on the replacement part and makes identification of the part easier:

 $A-Type\ of\ gas$ $515\ _{G20}\qquad 125\ _{G20}\qquad G20=Natural\ gas$ $515\ _{G30-G31}\qquad 125\ _{G30-G31}\qquad G30-G31=Butane-Propane\ (LPG)$ $B-Validity\ restrictions$ $515\ _{C)}\qquad 125\ _{C)}\qquad For\ models\ (M97R.24CM/F),\ only$

4.3 Composition of the replacement part code

Each replacement part code includes a table identification code and a position code. A position code is only listed for replacement parts which are currently available.

The replacement part code consists of the table code (which can be found on the upper right of the table) plus the position code (in two formats: individual part or kit).



The components of a kit are enclosed in a broken line. A kit may contain other complete kits, or portions of other kits.

In some tables, a replacement part may be identified with an arrow and a complete replacement part code (table code + position code). This means that the part is available, but must be ordered with the code listed. Also, any explanatory notes must be read before ordering.


=BI1011 515 =BI1011 515 (C) =BI1013 516 (D)

4.4 Using the replacement parts code

The replacement parts code must be included on all documents which are used in service reports, orders for replacement parts, guarantee claims, etc.

Spare parts list


Table		Edition	N° of pages
BI1411 Part 1	Water group	1109	1
BI1421 Part 1	Water group	1109	1
BI1462 Part 2	Water group	1109	1
BI1472 Part 2	Water group	1109	1
BI1303 Part 3	Gas group	1109	1
BI1323 Part 3	Gas group	1109	1
BI2065 Part 5	Driving panel and electric parts	1109	1
BI2075 Part 5	Driving panel and electric parts	1109	1
BI2095 Part 5	Driving panel and electric parts	1109	1
BI1546 Part 6	External panels, fire chamber	1109	1
BI1566 Part 6	External panels, fire chamber	1109	1
BI1911 Part 1	Spares	1109	1




M97R.24CM/F			
M97.24DM/F			ADIACI
			A BIASI

Part 1 - Water group


BI1421




M97R.24CM/F			
M97.24DM/F			ADIACI
			BIASI




M97R.24CM/F			
			ADIACI
			BIASI




M97.24DM/F			ADIACI
			A BIASI



M97.24DM/F			ADIACI
			BIASI




M97R.24CM/F			
			ADIACI
			BIASI



M97.24DM/F			ADIACI
			BIASI


Part 5 - Driving panel and electric parts

BI2075




M97R.24CM/F			
M97.24DM/F			ADIACI
			BIASI


BI2095




M97R.24CM/F			
			ADIACI
			A BIASI



M97.24DM/F			ADIACI
			BIASI





	800	O-ring packing set		
Part	Pos.	N.	T. Size	
BI1001	115	10	12,42 x 1,78	
KI1043	144	10	18,64 x 3,53	
BI1001	503	10		
BI1013	101	10		

BI1901	802	Flat packing set			
Part	Pos.	N.	T. Size		
BI1001	107	10	P 1/4"		
BI1001	109	10	P 3/8"		
BI1202	105	10	P 3/8"		
BI1001	106	10	P 1/2"		
BI1001	108	10	P 3/4"		
BI1001	105	10	P 1"		

1109

M97R.24CM/F			
M97.24DM/F			ADIACI
			BIASI